au by KDDI A5405SA

A Simple Manual (English Version)

Turning the Power On and Off

■Turning the Power On

Press and hold (POWER) for more than one second.

■Turning the Power Off

Press and hold (POWER) for more than one second.

Setting the Date and Time

You can set the phone to display the date and time on the stand-by screen. When this setting is enabled, the phone will receive current infomation for the local service area, and update its date and time settings accordingly.

Press ● → press 5 → press 2 → press 1 .

Checking Your Own Phone Number and E-mail Address

Press ● → press 0 .

Making a Call / Answering a Call

■Making a Call

Enter the phone number you want to call → press (ﾍｱ) .

To adjust the earpiece volume during a call : press ◎ .

To end the call : press (POWER) .

■Answering a Call

Press (ﾍｱ) while the phone is ringing.

Storing Data in the Address Book / Displaying the Address Book

■Storing Data in the Address Book

Press (ｱﾌﾟﾘ) for more than one second → press ◎ to select the item you want to store → press ● → enter the data → press (ｱﾌﾟﾘ) → press ● .

■Displaying the Address Book

Press (ｱﾌﾟﾘ) to display the Gyo(hiragana row) search screen → press ◎ to select the hiragana row under which the entry is stored → press ◎ to select the appropriate name → press ● to display the detail screen of the Address Book.

Setting the E-mail and EZweb Default Settings

Before you can begin using the E-mail and EZweb services, you must set the default settings. When you set the default settings,your E-mail address will be registered, allowing you to send and receive E-mail as well as access the internet.

Press (✉), (E) or (ｱﾌﾟﾘ) → press ● → set the default settings → press ● .

Using E-mail and C-mail

■E-mail

If you subscribed to the EZweb service when you purchased your phone,you will be able to use the E-mail service immediately. If you did not, please contact the au shop where you purchased your phone for further information. Make sure that you set the default settings before using the E-mail and EZweb services for the first time. (See "Setting the E-mail and EZweb Default Settings" above.)

■Sending an E-mail Message

Press (✉) → press 1 → press ◎ to select the 宛 input field → press ● → press ● → press 7 → enter the recipient's address → press ● → press (ｱﾌﾟﾘ) → press ◎ to select the 件 input field → press ● → enter the subject → press ● → press ◎ to select the ✎ input field → press ● → enter the message → press ● → press (ｱﾌﾟﾘ) → press 1 .

■Reading a Received E-mail Message

When you receive an E-mail message, "Eﾒｰﾙ X件"(X New E-mail), where X represents the number of messages received, will be displayed on the stand-by screen.

Press ◎ to select "Eﾒｰﾙ X件" → press ● → press ◎ to select "ﾒｲﾝﾌｫﾙﾀﾞ"(Main folder) → press ● → press ◎ to select the E-mail message you want to read → press ● .

■C-mail

Subscribers in areas other than the metropolitan area and Chubu district need to apply for a separate subscription to use C-mail.

■Sending a C-mail Message

Press (✉) for more than one second → press 1 → enter the message → press ● → press 1 → press 6 → enter the recipient's phone number → press (ｱﾌﾟﾘ) .

■Reading a Received C-mail Message

When you receive an C-mail message, "Cﾒｰﾙ X件"(X New C-mail), where X represents the number of messages received, will be displayed on the stand-by screen.

Press ◎ to select "Cﾒｰﾙ X件" → press ● .

Using EZweb

EZweb is an information service that allows you to enjoy easy internet access from your mobile phone.

If you subscribed to the EZweb service when you purchased your phone, you will be able to use the EZweb service immediately. If you did not, please contact the au shop where you purchased your phone for further information. Make sure that you set the default settings before using the E-mail and EZweb services for the first time. (See "Setting the E-mail and EZweb Default Settings" above.)

Press (E) → press 1 → select the website you want to view.

Using the Camera (Photo/Movie)

■Taking a Photo

Press ● → press ◎ to select "カメラ"(Camera) → press ● → press 1 → press ● to take the photo → press ● to save the image.

■Recording a Movie Clip

Press ● → press ◎ to select "カメラ"(Camera) → press ● → press 2 → press ● to start recording the movie clip → press ● to stop recording → press ● to save the image.

Making an International Call

Example: To call United States, number 212-123-XXXX.

Access code 005345 → 1 (Country code (USA)) → Area code 212 → 123XXXX (Subscriber's number) → press (ﾍｱ) .

English Announcement Function

This function allows you to set the phone so that Voice Mail service operation instructions and answering messages are played in english.

Press ● → press 5 → press 5 → press 6 → press (ﾍｱ) .

Other Handy Features

■Setting the Manner Mode

Press (ｸﾘｱ ﾏﾅｰ) for more than one second.

To disable the Manner Mode, press (ｸﾘｱ ﾏﾅｰ) for more than one second from the stand-by screen.

■Setting the Voice Record Function

Press (ﾒﾓ) for more than one second.

To disable the Voice Record function, press (ﾒﾓ) for more than one second from the stand-by screen.

For inquiries, please contact

au Customer Service Center (General Information)

■If you are calling from a landline phone : 0077-7-111(toll free)

■If you are calling from an au mobile phone : 157(toll free)